

ACCELEVATION ELEVATE SLIDING DOOR OPERATION & MAINTENANCE GUIDE

Operation

Tools Required:

- Allen Wrench


Close Speed Adjustment:

- Rotary spring assembly is rated for 400,000 cycles, approximately 4 years.
- To adjust closing speed/dampening characteristics, use an allen wrench to remove the valance cover and set aside. Adjust closing speed by turning the bracket dials.



Turn **CLOCKWISE** toward MAX to slow down door closing speed
Turn **COUNTER-CLOCKWISE** toward MIN to speed up the door closing speed

Adjust dials by quarter turns, and check the results
For Dual doors, adjust both left and right dials evenly



Maintenance

Supplies Required:

- Microfiber Cloth
- Mild Detergent
- Isopropyl Alcohol (Optional)

Cleaning:

1. The panel inserts may be cleaned using a soft, microfiber cloth with mild detergent, and warm water. **Chemicals are not advised.**
2. The aluminum frame, handles, and hinges may be cleaned with a soft, microfiber cloth, mild detergent, and warm water. Alternatively, isopropyl alcohol may be used.

